DCS210 5/8 Amp DCC Command Station & Booster (not sold separately)



Power Input (DC ONLY)	Max: 25 VDC Min: 13.8 VDC
Maximum Output Current	8 Amps
Locomotive Addresses	100
Throttle Support	100
Programming Track	Yes, Separate
Program read/write	Yes
Stationary Decoder Addresses	999
2 & 4 Digit Addressing	Yes, (address range 9999)
Function Control	30 (F0Fwd, F0Rev and F1-F28)
Consisting	Yes, UniVersal or Advanced
Speed Steps	14,28,128

Prod Date	10/12/2016	Discontinued	Current	Replaced By	Current
MSRP				SKU	

	DCS240 Option Switch Table		
Option Switch #	Effect on System operation when "Closed"		
OpSw 01	Do Not Change	Setting t	
OpSw 02	t = Command Station Mode c = Booster only Mode (not recommended)		
OpSw 03	t = DCS210's booster normal $c = DCS210's booster is auto reversing$		
OpSw 04	Do Not Change	t	
OpSw 05	Do Not Change	t	
OpSw 06	t = check for decoder before programmingc = program without checking for a decoder		
OpSw 07	Do Not Change	t	
OpSw 08	Do Not Change	t	
OpSw 09	Do Not Change	с	
OpSw 10	Do Not Change	с	
OpSw 11	Do Not Change	t	
OpSw 12	Do Not Change		
OpSw 13	t = Loco address purge time 200 seconds c = Loco address purge time 600 seconds		
OpSw 14	c = Loco address purging enabled t = Loco address purging disabled	t	
OpSw 15	t = Purging will not change loco speed c = Purging will force a loco to 0 speed	t	
OpSw 16	Do Not Change	t	
OpSw 17	t = Automatic advanced decoder assisted [FX] consists are enabled c = Automatic advanced decoder assisted [FX] consists are disabled		
OpSw 18	t = Normal DCS210 booster short circuit shutdown time c = Extended DCS210 booster short circuit shutdown time		
OpSw 19	Do Not Change		
OpSw 20	t = enable address 00 or analog stretching for conventional locos c = Disable address 00 or analog stretching for conventional locos		
OpSw 21	OPSW 21-23 set the global system default type for "NEW" loco selections SW21/22/23 set as follows:		
OpSw 22	-c-c-t = 128 step mode c-c-c = 128 step FX mode t = 14 step mode	С	
OpSw 23	t-c-t = 14 step mode t-t-t = 28 step mode	t	
OpSw 24	Do Not Change	t	
OpSw 25	t = Enable Route echo over LocoNet c = Disable Route echo over LocoNet	t	

OpSw 26 $t = Disable routes$		с	
	c = Enable routes		
OpSw 27	t = Enable normal switch commands, a.k.a. the "Bushby bit."		
	c = Disable normal switch commands, a.k.a. the "Bushby bit."		
<u> </u>	Allows attached PC to handle switch control logic		
OpSw 28	t = Enable interrogate commands at power on	t	
0 0 00	c = Disable interrogate commands at power on	t	
OpSw 29	Do Not Change		
OpSw 30	Do Not Change		
OpSw 31	t = Normal route/switch output rate when not trinary	t	
	c = Fast route/switch output rate when not trinary		
OpSw 32	Do Not Change		
OpSw 33	t = Track power off at power on		
	c = Allows track power to restore to prior state at power on		
OpSw 34	t = Disallow track to power up to run state, if set to run prior to	t	
	power on		
	c = Allows track to power up to run state, if set to run prior to power		
	on		
OpSw 35	t = Enables Loco Reset Button	t	
	c = Disables Loco Reset Button		
OpSw 36*	c = Clears all mobile decoder info & consists	t	
OpSw 37*	c = Clears all routes		
OpSw 38	Sw 38 $t = \text{Loco Reset Button activates OpSw39}$		
	c = Loco Reset Button activates Slot Zero (see section 10.11)		
OpSw 39*	c = Clears all internal memory states, including OpSw 36, 37	t	
OpSw 40*	c = Clears all internal memory states and sets Voltage Trim to	t	
-	default. Resets DCS210 to factory default		
OpSw 41	Diagnostic click disabled t		
	c = Diagnostic click when valid LocoNet commands incoming &	7	
	routes being output		
OpSw 42	t = Enable 2 short beeps when loco address purged	t	
	c = Disable 2 short beeps when loco address purged		
OpSw 43	t = Enable LocoNet update of command station's track status	t	
<u> </u>	c = Disable LocoNet update of command station's track status		
OpSw 44	Do Not Change	t	
OpSw 45	t = Enable reply for switch state request	t	
	c = Disable reply for switch state request		
OpSw 46	Do Not Change	t	
OpSw 47	t = Normal Program Track Setting		
	c = Program track is brake generator when not programming.	t	
	Braking is DCC set to speed 0 (not Emergency stop) for address 0,		
	light ON, broadcast to all addresses		

Digitrax, Inc. is not responsible for unintentional errors or omissions in this document.

Page 4 of 4